



ESP Classic

2 piece stringing

Recommended string Ektelon Premier Power 18 gauge

String pattern 18X20 Power Ring 9

Length 24' Mains x 16' Crosses

Recommended tension is 30 +/- 4

Mains skip holes at 6H, 9H, 11H, 12H, & 13H

Shared holes at 8H & 14H

Helpful hint: when stringing certain main strings, insert a piece of scrap string before pulling tension in order to help expose cross holes. Before pulling tension on the cross strings, the scrap string can be removed.

Mains

1. Start at bottom of throat by Center Power Ring (CPR). Insert 12 feet of string on right side of CPR to 1HR and clamp (do not pull tension).
2. Insert other side of string on left side of CPR to 1HL, tension and clamp.
3. Feed string from 1HL to 2HL down to Left Power Ring (LPR) #2 to 3HL, tension and clamp.
4. Feed string from 1HR to 2HR down to Right Power Ring (RPR) #2 to 3HR, tension and clamp.
5. Feed string from 3HL to 4HL down to LPR #3 to 5HL, tension and clamp.
6. Feed string from 3HR to 4HR down to RPR #3 to 5HR, tension and clamp.
7. Feed string from 5HL to 7HL down to LPR #4 to 8HL (shared hole), tension and clamp.
8. Feed string from 5HR to 7HR down to RPR #4 to 8HR (shared hole), tension and clamp.
9. Feed string from 8HL to 10HL down to LPR #5 to 14HL, tension and clamp.
10. Feed string from 8HR to 10HR down to RPR #5 to 14HR, tension and clamp.
11. Tie off mains at 10HL and 10HR.

Crosses

1. Tie starting knot at 7HL
2. Start crosses at 6HL across to 6HR, tension and clamp.
3. Feed string from 6HR to 8HR(shared hole) across to 8HL (shared hole), tension and clamp.
4. Feed string from 8HL to 9HL across to 9HR, tension and clamp.
5. Feed string from 9HR to 11HR across to 11HL, tension and clamp.
6. Feed string from 11HL to 13 HL across to 13HR, do not pull tension.
7. Feed string from 13HR to 12HR across to 12HL, do not pull tension.
8. Feed string from 12HL to 14HL (shared hole) across to 14HR (shared hole).
9. Pull tension and clamp at 13HR and then pull tension and clamp at 12HL.
10. Continue installing cross strings conventionally and tie off at 2TL.



ESP RG Toron

2 piece stringing

Recommended string Ektelon Premier Power 17 gauge

String pattern 12X16 DPR

Length: 20' Mains x 14' Crosses

Recommended tension is 34 +/- 4

Mains skip holes at 5H & 7H

Double barrel grommet at 8H

Stack Left DPR from bottom up and Right DPR from top down

Helpful hint: when stringing certain main strings, insert a piece of scrap string before pulling tension in order to help expose cross holes. Before pulling tension on the cross strings, the scrap string can be removed.

Mains

1. Start at top of frame and insert 10 feet of string from 1HR to Right Power Ring (RPR) to 4HR, clamp string at 1HR (do not pull tension on this string yet)
2. Insert other side of string at 1HL to Left Power Ring (LPR) to 4HL, tension and clamp.
3. Tension 4HR and clamp
4. Feed string from 4HL to 6HL down to LPR up to 2HL, tension and clamp.
5. Feed string from 4HR to 6HR down to RPR up to 2HR, tension and clamp.
6. Feed string from 2HL to 3HL down to LPR up to 8HL upper hole, tension and clamp.
7. Feed string from 2HR to 3HR down to RPR up to 8HR lower hole, tension and clamp.
8. Tie off mains at 6HL and 6HR.

Crosses

1. Tie starting knot at 4HL and feed string from 5HL to 5HR, tension and clamp.
2. Feed string from 5HR to 7HR across to 7HL, tension and clamp.
3. Feed string from 7HL to 8HL lower hole across to 8HR upper hole, tension and clamp.
4. Feed string from 8HR to 9HR across to 9HL, tension and clamp.
5. Feed string from 9HL to 11HL across to 11HR, do not pull tension.
6. Feed string from 11HR to 10HR across to 10HL, do not pull tension.
7. Tension and clamp 11HR and then 10HL.
8. Feed string from 10HL to 12HL across to 12HR, tension and clamp.
9. Continue installing crosses conventionally and tie off