


# STRINGING INSTRUCTIONS



## RED, SILVER & BLACK



### String Instructions

#### 2-Piece Stringing

String tension: 30 +/- 4

String pattern: DPR 16 x 19

Length: 23' Mains x 15' Crosses

#### Mains

Mount the racquet to the stringing machine with Ektelon logo on the handle facing up. Start at head. M's skip at 5H, 7H, 9H, 10H, 12H, 13H, and 14H.

#### Short Side

1. 1H-L to left Pin 1
2. Left pin 1 to 2H-L (tension and clamp)
3. 1H-R to right Pin 1
4. Right pin 1 to 2H-R (tension and clamp)
5. 3H-L to left Pin 2
6. Left pin 2 to 4H-L (tension and clamp)
7. 3H-R to right Pin 2
8. Right pin 2 to 4H-R (tension and clamp)
9. 6H-L to left Pin 3
10. Left pin 3 to 8H-L (tension and clamp)
11. 6H-R to right Pin 3
12. Right pin 3 to 8H-R (tension and clamp)
13. 11H-L to left Pin 4
14. Left pin 4 to 15H-L (tension and clamp) and tie-off at 11H-L
15. 11H-R to right Pin 4
16. Right pin 4 to 15H-R (tension and clamp) and tie-off at 11H-R

#### Crosses

1. Tie starting knot at 6H-R
2. Start at 5H-R and weave across to 5H-L, then down to 7H-L and across to 7H-R.
3. Continue installing cross strings conventionally. Finish and tie off at 4T-L.

\* It is recommended to use a table-brake when stringing cross strings on all O3 Racquets.