



O3 Tour 165 – RX57C

2 piece stringing

Recommended string is Ektelon Lightning 17 gauge

String Pattern 16 x 19 Power Ring 8

Length 22' Mains x 18' Crosses

Suggested tension range is 34 +/- 4

Mains skip holes at 5H,7H,9H,10H,12H,13H,14H

Tie off Mains at 11H

Tie off Crosses at 6HR & 2TL

Helpful hint: when stringing certain main strings, insert a piece of scrap string before pulling tension in order to help expose cross holes. Before pulling tension on the cross strings, the scrap strings should be removed.

Mains

1. Mount racquet with 2 grommets in throat on left side
2. Feed 11' of string from 1HR to Right Power Ring (RPR)#1, continue around to 2HR
3. Clamp string at 1HR, but do not tension yet
4. Feed other end of string from 1HL to Left Power Ring (LPR)#1, continue around to 2HL
5. Pull tension and clamp at 2HL
6. Pull tension and clamp at 2HR
7. Feed string from 2HL to 3HL down to LPR #2 around to 4HL, tension and clamp
8. Feed string from 2HR to 3HR down to RPR #2 around to 4HR, tension and clamp
9. Feed string from 4HL to 6HL down to LPR #3 around to 8HL, tension and clamp
10. Feed string from 4HR to 6HR down to RPR#3 around to 8HR, tension and clamp
11. Feed string from 8HL to 11HL down to LPR #4 around to 15HL, tension and clamp
12. Feed string from 8HR to 11HR down to RPR#4 around to 15HR, tension and clamp
13. Tie off mains at 11HL & 11HR

Crosses

1. Tie starting knot at 6HR and feed string from 5HR to 5HL, tension and clamp
2. Feed string from 5HL to 7HL across to 7HR, tension and clamp
3. Feed string from 7HR to 9HR across to 9HL, tension and clamp
4. Continue stringing crosses conventionally and tie off at 2TL

** It is recommended to use a table brake when stringing crosses on O3 racquets*

Ektelon
17110 Marcy Street, LL02
Omaha, NE 68118
800.283.2635